

INNO-PROOF FOX BUTIL-TAPE

Aging Resistant Self-Adhesive Butyl Tape for Waterproofing Applications with Polypropylene Felt Carrier

Description

FOX BUTIL-TAPE, polypropylene felt carrier, aging resistant self-adhesive butyl tape that provides very good adhesion on different material joint details and is compatible with waterproofing products.

Fields of Application

- Wet area (bathroom, balcony, terrace, roof, pool, industrial kitchens) waterproofing applications
- In horizontal, vertical joint and chamfer insulation
- Insulation of shower duct surrounds and drain units
- In ceramic and natural stone applications



Advantages

- Easy and fast to apply,
- It is long-lasting,
- It is resistant to aging.
- Since it is butyl based, it has very good adhesion properties. It is resistant to chemical liquids.

Technical Properties

Structure of Material	Carrier (bottom and top) Coating	Polypropylene (PP) felt Aging resistant high flexibility self-adhesive butyl rubber
Color		Grey
Breaking Load-Longitudinal	DIN EN ISO 527-3	30 N/15 mm
Breaking Load-Transverse	DIN EN ISO 527-3	19 N/15 mm
Breaking Load-Longitudinal	DIN EN ISO 527-3	60%
Breaking Load-Transverse	DIN EN ISO 527-3	80%
Puncture Pressure		>0,2 bar

Package

Roll Dimensions: 0,10 x 20 mt and 0,20 x 20 mt



Storage

Store in a cool, dry place away from sunlight.

Disclaimer

The data contained in this technical document is based on our scientific and practical knowledge. SARTECH Yapı Malzemeleri San. ve Tic. Ltd Şti. is only responsible for the quality of the product. SARTECH Yapı Malzemeleri San. ve Tic. Ltd Şti. cannot be held responsible for the consequences that may occur due to misuse and/or other than the written recommendations on where and how to use the product. The responsibility for the correct application of our product lies with the user. Our company is only responsible for the quality of the product. This catalog overrides the information in the previous catalogue. Our company reserves the right to make changes in any information and content details in this catalogue. It is essential to check that the information in the catalog is up-to-date and valid. All rights reserved.






Step 1

The floor must be insulated with a suitable liquid waterproofing material.




Step 2

It is prepared by cutting butyl tape in appropriate sizes around the shower channel, strainer or drain unit.



Step 3

After the surface preparation is completed, the shower channel, strainer is placed on the floor and the butyl tape is adhered to the floor and it is ensured that it is well adhered to the floor on which it is applied with a pressure roller.



Step 4

After the insulation application is completed, ceramic application can be started.

